

# SPARE PARTS LIST

MODEL NO. 6307

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	182862-9	HOUSING SET INC. 19	1	
002	859269-1	NAME PLATE 6307	1	
003	265995-6	TAPPING SCREW 4X18	8	
004	651986-7	SWITCH TG803TLB-1	1	
005	763115-1	DRILL CHUCK S13	1	
006	153253-1	GEAR COMPLETE	1	
007	210047-8	BALL BEARING 626Z	1	
008	633338-4	FIELD 220/240V	1	
009	211030-8	BALL BEARING 627Z	1	
010	517198-1	ARMATURE ASSY 220/240V INC. 9,11,12	1	
011	241881-5	FAN 52	1	
012	211030-8	BALL BEARING 627Z	1	
013	191962-4	CARBON BRUSH CB-419	1	
014	643936-6	BRUSH HOLDER	2	
015	265995-6	TAPPING SCREW 4X18	2	
016	687053-2	STRAIN RELIEF	1	
017	682504-0	CORD GUARD 10-85	1	
018	691015-4	POWER SUPPLY CORD 0.75-2-2.5	1	
019	182862-9	HOUSING SET INC. 1	1	
020	819063-3	MAKITA LABEL	1	
A01	763430-3	CHUCK KEY S13	1	
E03	410102-8	KEY HOLDER	1	
E04	191962-4	CARBON BRUSH CB-419	2	
E05	534023-1	LEAD ASS'Y (ORANGE)	1	
E06	534024-9	LEAD ASS'Y (PURPLE)	1	
E07	534027-3	LEAD ASS'Y (BLACK)	1	