

SPARE PARTS LIST

MODEL NO. RP1800

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	125542-4	THUMB SCREW M10X115 ASS'Y	1	
002	450946-4	DEPTH POINTER	1	
003	252643-6	WING NUT M10	1	
004	410129-8	NYLON NUT M10	1	
005	265995-6	TAPPING SCREW 4X18	2	
006	450948-0	REAR COVER	1	
007	158999-4	MOTOR HOUSING COMPLETE	1	
009	866366-6	RP1800 NAME PLATE	1	
010	654531-7	TERMINAL BLOCK 2P	1	
013	682505-8	CORD GUARD 10-90	1	
014	691015-4	POWER SUPPLY CORD 0.75-2-2.5	1	
015	687053-2	STRAIN RELIEF	1	
016	265995-6	TAPPING SCREW 4X18	2	
017	450949-8	COVER	1	
018	265995-6	TAPPING SCREW 4X18	2	
019	266059-9	TAPPING SCREW 5X75	2	
020	636338-3	FIELD 220V	1	
021	450944-8	BUFFLE PLATE	1	
022	211092-6	BALL BEARING 629DDW	1	
023	681671-8	INSULATION WASHER	1	
024	517798-7	ARMATURE ASS'Y 220V INC. 22,23,25	1	
025	240112-9	FAN 80	1	
026	251295-0	+ COUNTERSUNK HEAD SCREW M4X14	3	
027	285731-4	BEARING RETAINER 60	1	
028	211380-1	BALL BEARING 6205DDW	1	
029	265995-6	TAPPING SCREW 4X18	2	
030	450937-5	GRIP COVER R	1	
031	450940-6	SWITCH LEVER	1	
032	233024-3	COMPRESSION SPRING 4	1	
033	450941-4	LOCK OFF BUTTON	1	
034	231372-4	COMPRESSION SPRING 5	1	
035	651432-0	SWITCH	1	
036	911343-4	PAN HEAD SCREW M6X25	1	
037	450936-7	GRIP R	1	
038	450942-2	PUSH BUTTON	1	
039	233072-2	COMPRESSION SPRING 8	1	
040	268234-3	COLLARED PIN 6	1	
041	911133-5	PAN HEAD SCREW M4X18	2	
042	763622-4	COLLET CONE 1/2"	1	
043	763674-5	COLLET NUT	1	
044	318382-9	RETAINER COVER	1	
045	285849-1	RETAINER	1	
046	158971-6	MOTOR BRACKET COMPLETE	1	
047	266012-5	TAPPING SCREW 5X35	4	
048	153476-1	HALF NUT COMPLETE	1	
049	231231-2	COMPRESSION SPRING 12	1	
050	911343-4	PAN HEAD SCREW M6X25	1	
051	265995-6	TAPPING SCREW 4X18	2	
052	450939-1	GRIP COVER L	1	
053	450938-3	GRIP L	1	
054	643700-5	BRUSH HOLDER CAP 7-18	2	
055	B-80139	CARBON BRUSH SET CB-203A	1	
059	233538-2	TORSION SPRING 15	1	
060	266015-9	SET BOLT M10	1	
061	450950-3	LOCK LEVER	1	
062	911213-7	PAN HEAD SCREW M5X12	1	
063	450943-0	SILENT POLE	1	
064	234106-4	COMPRESSION SPRING 13	1	
065	325652-9	SCREW M10	1	
066	450953-7	TIP DEFLECTOR	1	

SPARE PARTS LIST

MODEL NO. RP1800

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
067	251467-7	- FLAT HEAD SCREW M6	1	
068	213030-4	O RING 8	1	
069	265587-1	+HEX. BOLT M5X20	1	
070	265586-3	+HEX. BOLT M5X14	1	
071	315931-3	STOPPER	1	
072	265587-1	+HEX. BOLT M5X20	1	
073	216009-4	STEEL BALL 7.1	1	
074	231419-4	COMPRESSION SPRING 5	1	
075	265720-5	THUMB SCREW M5X14	1	
076	231240-1	COMPRESSION SPRING 7	1	
077	253783-3	FLAT WASHER 6	1	
078	931303-0	HEX. NUT M6	1	
079	265774-2	THUMB SCREW M4X19	1	
080	213022-3	O RING 3	1	
081	265720-5	THUMB SCREW M5X14	1	
082	231240-1	COMPRESSION SPRING 7	1	
083	417252-0	POLE	1	
084	234105-6	COMPRESSION SPRING 11	1	
085	158973-2	BASE COMPLETE	1	
086	424176-3	CAP 14	1	
087	346032-6	LOCK PLATE	1	
088	233105-3	COMPRESSION SPRING 4	2	
089	450951-1	BASE PLATE	1	
090	912112-6	COUNTERSUNK HEAD SCREW M4X10	4	
091	266016-7	SET BOLT M5X10	2	
A01	342428-9	STRAIGHT GUIDE	1	
A02	266491-7	+PAN HEAD SCREW M6X135	1	
A03	763803-0	COLLET SLEEVE FOR 1/4" BIT	1	
A04	763805-6	COLLET SLEEVE FOR 3/8" BIT	1	
A05	781030-7	WRENCH 24	1	
A06	941152-7	FLAT WASHER 6	1	
A07	344364-5	TEMPLET GUIDE 16	1	
A08	122700-3	GUIDE HOLDER ASS'Y	1	
A09	123022-4	TRIMMER GUIDE ASS'Y	1	
A10	158980-5	KNOB 55 COMPLETE	1	
A11	D-07901	STRAIGHT BIT 12E	1	