



This movie was filmed in Japan.  
Models and specs may vary by country.

Angle Grinder



DGA418

DGA414

DGA518

DGA514

Drywall Sander  
DSL800



Backpack Vacuum Cleaner  
DVC265 Bluetooth®



DVC665

Punge Cut Saw  
DSP601



Vacuum Cleaner  
DVC864L



Vacuum Cleaner  
DVC154



The vacuum cleaner is activated  
by a battery tool via a wireless  
connection device

**HEPA  
filter**



Auto-start Wireless System

Switch on the tool, and  
Vacuum cleaner is activated

It has been impossible, but now Vacuum cleaner  
can be automatically activated by Cordless tools  
with our newly developed wireless system.



Auto-start Wireless System

Switch on the tool



Vacuum cleaner  
is activated

Circular Saw



Combination Hammer  
DHR182

Planer  
DKP181



Wireless adapter set

This adapter enables to  
use with supported AC  
vacuum cleaners  
equipped with  
auto start/ stop  
functions.



Part No.  
WUT02 (199818-5)

Wireless unit



Part No.  
WUT01 (199393-1)

Rotary Hammer  
DHR400



Combination Hammer  
DHR282



AWS connects to power tool with Bluetooth

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc.  
and any use of such marks by Makita is under license. Other trademarks and trade names are those  
of their respective owners.